


DAEMON OLED SERIES- Water Temp. Gauge

Package Contents Gauge*1 / Temp Sensor*1 / Sensor Wire(2pin)*1 / Power Box*1 / Gauge Wire (6pin)*1 / Gauge Stand*1 / Operation Manual*1

Installation Diagram


Suggestions Before Installation

1. Cut the radiator hose to fit the length of water adaptor.
2. Install the Temp. Sensor to water adaptor first.



To avoid damage, please ensure the RED wire is attached to the ignition switch that connected to Coil.

Ignition Switch Diagram



⚠ WARNING


1. Please must follow all installations in this manual to ensure safe installation and operation of the product.
2. DO NOT disassemble or reassemble the product. This might cause damage or make them unsafe to use. When the product is disassembled or reassembled, the Warranty can't be offered.
3. Before installation, please make sure the engine is switched off and the vehicle is stationary.
4. Due to possible injury from contact with a hot engine or exhaust pipe, DO NOT begin installation until the vehicle is cool.
5. When attaching wires for the product, please take care so that the product's wires do not interfere with existing wires.
6. This product is only for use on vehicles with 12V electronic system.

⚠ CAUTION





1. To avoid water leaks during installation of the sensor, please use Telfon tape while installation.
2. To avoid water leaks, please ensure the size of adaptor is suited.
3. To avoid damage, please make sure using insulating tape or bushing while connection.
4. To avoid damage of sensor wire, please fix the waterproof connector on the vehicle body.
5. Coolant spills by the installation work. Please replenish the engine with coolant and bleed the air from the system, or, the engine might overheat.

DAEMON Remote Controller Operation Manual







Tips of Remote Controller Operation for Water Temp

1. Please have the remote controller point to the gauge you are going to set up.
2. In setting process, idle any button for 5 seconds or press  directly; the gauge will leave setting mode and save automatically.
3. A "beep" sound will be heard while the new setting is done.





• Color Setting

1. Select Water Temp. Gauge icon by press  on Remote Controller.
2. Then press  for entering the color selection mode. Again, press the  for different color selection. Press  or idle any button for 5 seconds to leave the setting mode.

• Warning Value Setting (When the value is below, the warning will be functional)

1. Select Water Temp. Gauge icon by press  on Remote Controller.
2. Press  or  for entering the warning setting mode. Press  or  to adjust the warning value. Press  or idle any button for 5 seconds to leave the setting mode.

• Peak Value Setting

1. Select Water Temp. Gauge icon by press  on Remote Controller.
2. Press  to display peak value record, or, press  to clear peak value record. Press  or idle any button for 5 seconds to leave the setting mode.

• OLED Display Function

When the Gauge is Booting, the OLED will show the Peak Value and warning setting value.


• Sensor Failure warning Function

After Booting, the gauge buzzer will show the warning sound about 20 seconds if the sensor is failed.

DAEMON OLED SERIES- Oil Temp. Gauge


Package Contents Gauge*1 / Temp Sensor*1 / Sensor Wire(2pin)*1 / Power Box*1 / Gauge Wire (6pin)*1 / Gauge Stand*1 / Operation Manual*1

Installation Diagram



To avoid damage, please ensure the RED wire is attached to the ignition switch that connected to Coil.

Ignition Switch Diagram



⚠ WARNING


1. Please must follow all installations in this manual to ensure safe installation and operation of the product.
2. DO NOT disassemble or reassemble the product. This might cause damage or make them unsafe to use. When the product is disassembled or reassembled, the Warranty can't be offered.
3. Before installation, please make sure the engine is switched off and the vehicle is stationary.
4. Due to possible injury from contact with a hot engine or exhaust pipe, DO NOT begin installation until the vehicle is cool.
5. When attaching wires for the product, please take care so that the product's wires do not interfere with existing wires.
6. This product is only for use on vehicles with 12V electronic system.

⚠ CAUTION





1. To avoid oil leaks during installation of the sensor, please use Telfon tape while installation.
2. To avoid oil leaks, please ensure the size of oil adaptor is suited.
3. To avoid damage, please make sure using insulating tape or bushing while connection.
4. To avoid damage of sensor wire, please fix the waterproof connector on the vehicle body.
5. Coolant spills by the installation work. Please replenish the engine with coolant and bleed the air from the system, or, the engine might overheat.

DAEMON Remote Controller Operation Manual







Tips of Remote Controller Operation for Water Temp

1. Please have the remote controller point to the gauge you are going to set up.
2. In setting process, idle any button for 5 seconds or press  directly; the gauge will leave setting mode and save automatically.
3. A "beep" sound will be heard while the new setting is done.





• Color Setting

1. Select Oil Temp. Gauge icon by press  on Remote Controller.
2. Then press  for entering the color selection mode. Again, press the  for different color selection. Press  or idle any button for 5 seconds to leave the setting mode.

• Warning Value Setting (When the value is below, the warning will be functional)

1. Select Oil Temp. Gauge icon by press  on Remote Controller.
2. Press  or  for entering the warning setting mode. Press  or  to adjust the warning value. Press  or idle any button for 5 seconds to leave the setting mode.

• Peak Value Setting

1. Select Oil Temp. Gauge icon by press  on Remote Controller.
2. Press  to display peak value record, or, press  to clear peak value record. Press  or idle any button for 5 seconds to leave the setting mode.

• OLED Display Function

When the Gauge is Booting, the OLED will show the Peak Value and warning setting value.

• Sensor Failure warning Function

After Booting, the gauge buzzer will show the warning sound about 20 seconds if the sensor is failed.

DAEMON OLED SERIES- Oil Press. Gauge


Package Contents

Gauge*1 / Oil Press Sensor*1 / Oil Sensor Wire(3pin)*1
/ Gauge Wire (6pin)*1/ Gauge Stand*1/ Power Box*1 / Operation Manual*1

Installation Diagram


Suggestions Before Installation

1. Cut the radiator hose to fit the length of water adaptor.
2. Install the Temp. Sensor to water adaptor first.



To avoid damage, please ensure the RED wire is attached to the ignition switch that connected to Coil.

Ignition Switch Diagram



⚠ WARNING


1. Please must follow all installations in this manual to ensure safe installation and operation of the product.
2. DO NOT disassemble or reassemble the product. This might cause damage or make them unsafe to use. When the product is disassembled or reassembled, the Warranty can't be offered.
3. Before installation, please make sure the engine is switched off and the vehicle is stationary.
4. Due to possible injury from contact with a hot engine or exhaust pipe, DO NOT begin installation until the vehicle is cool.
5. When attaching wires for the product, please take care so that the product's wires do not interfere with existing wires.
6. This product is only for use on vehicles with 12V electronic system.

⚠ CAUTION (Oil Press)





1. To avoid oil leaks during installation of sensor, please use Telfon tape while installation. Before driving, inspect tubing and oil blocks for leaks. Leaks could cause a fire or damage the engine.
2. To avoid oil leaks, please ensure the size of adaptor is suited.
3. To avoid the damage of sensor wire, please fix the waterproof connector on the vehicle body.
4. Oil spills by the installation work. Please replenish the engine with oil. The engine might overheat when oil is too little.

DAEMON Remote Controller Operation Manual







Tips of Remote Controller Operation for Oil Press

1. Please have the remote controller point to the gauge you are going to set up.
2. In setting process, idle any button for 5 seconds or press  directly; the gauge will leave setting mode and save automatically.
3. A "beep" sound will be heard while the new setting is done.





• Color Setting

1. Select Oil Press. Gauge icon by press  on Remote Controller.
2. Then press  for entering the color selection mode. Again, press the  for different color selection. Press  or idle any button for 5 seconds to leave the setting mode.

• Warning Value Setting (When the value is below, the warning will be functional)

1. Select Oil Press. Gauge icon by press  on Remote Controller.
2. Press  or  for entering the warning setting mode. Press  or  to adjust the warning value. Press  or idle any button for 5 seconds to leave the setting mode.

• Peak Value Setting

1. Select Oil Press. Gauge icon by press  on Remote Controller.
2. Press  to display peak value record, or, press  to clear peak value record. Press  or idle any button for 5 seconds to leave the setting mode.

• OLED Display Function

When the Gauge is Booting, the OLED will show the Peak Value and warning setting value.


• Sensor Failure warning Function

After Booting, the gauge buzzer will show the warning sound about 20 seconds if the sensor is failed.

DAEMON OLED SERIES - Boost Gauge


Package Contents Gauge*1 / Boost Sensor*1 / Boost Sensor Wire(3pin)*1 / Power Box*1 / Air Filter*1
Gauge Wire (6pin)X1 / Three Way Joint*1 / Rubber Hose*1 / Gauge Stand*1 / Operation Manual*1

Installation Diagram



To avoid damage, please ensure the RED wire is attached to the ignition switch that connected to Coil.

Ignition Switch Diagram



⚠ WARNING


1. Please must follow all installations in this manual to ensure safe installation and operation of the product.
2. DO NOT disassemble or reassemble the product. This might cause damage or make them unsafe to use. When the product is disassembled or reassembled, the Warranty can't be offered.
3. Before installation, please make sure the engine is switched off and the vehicle is stationary.
4. Due to possible injury from contact with a hot engine or exhaust pipe, DO NOT begin installation until the vehicle is cool.
5. When attaching wires for the product, please take care so that the product's wires do not interfere with existing wires.
6. This product is only for use on vehicles with 12V electronic system.

⚠ CAUTION (Boost)





1. Please avoid install sensor nearby heat.
2. To avoid disconnection of rubber hose during pipe installation, suggest using tie-wraps to tie up.

DAEMON Remote Controller Operation Manual







Tips of Remote Controller Operation for Boost

1. Please have the remote controller point to the gauge you are going to set up.
2. In setting process, idle any button for 5 seconds or press  directly; the gauge will leave setting mode and save automatically.
3. A "beep" sound will be heard while the new setting is done.





• Color Setting

1. Select Boost Gauge icon by press  on Remote Controller.
2. Then press  for entering the color selection mode. Again, press the  for different color selection. Press  or idle any button for 5 seconds to leave the setting mode.

• Warning Value Setting (When the value is exceeded, the warning will be functional)

1. Select Boost Gauge icon by press  on Remote Controller.
2. Press  or  for entering the warning setting mode. Press  or  to adjust the warning value. Press  or idle any button for 5 seconds to leave the setting mode.

• Peak Value Setting

1. Select Boost Gauge icon by press  on Remote Controller.
2. Press  to display peak value record, or, press  to clear peak value record. Press  or idle any button for 5 seconds to leave the setting mode.

• OLED Display Function

When the Gauge is Booting, the OLED will show the Peak Value and warning setting value.

• Sensor Failure warning Function

After Booting, the gauge buzzer will show the warning sound about 20 seconds if the sensor is failed.

DAEMON OLED SERIES - ALL IN ONE (EXT.TEMP) Gauge


Package Contents

Gauge*1 / Ext.Temp Sensor*1 / Ext.Temp Sensor Wire(2pin)*1 / Temp Sensor*2 / Temp Sensor Wire(2pin)*2 / Power Box*1 / Gauge Wire (6pin)X1 / Gauge Stand*1 / Operation Manual*1

Installation Diagram


Attention:

Please avoid over bend the sensor steel wire, or the sensor will be breakdown.



To avoid damage, please ensure the RED wire is attached to the ignition switch that connected to Coil.

Ignition Switch Diagram




WARNING





1. Please must follow all installations in this manual to ensure safe installation and operation of the product.
2. DO NOT disassemble or reassemble the product. This might cause damage or make them unsafe to use. When the product is disassembled or reassembled, the Warranty can't be offered.
3. Before installation, please make sure the engine is switched off and the vehicle is stationary.
4. Due to possible injury from contact with a hot engine or exhaust pipe, DO NOT begin installation until the vehicle is cool.
5. When attaching wires for the product, please take care so that the product's wires do not interfere with existing wires.
6. This product is only for use on vehicles with 12V electronic system.

DAEMON Remote Controller Operation Manual







Tips of Remote Controller Operation for Ext. Temp

1. Please have the remote controller point to the gauge you are going to set up.
2. In setting process, idle any button for 5 seconds or press  directly; the gauge will leave setting mode and save automatically.
3. A "beep" sound will be heard while the new setting is done.





• Color Setting

1. Select Exhaust Temp. Gauge icon by press  on Remote Controller.
2. Then press  for entering the color selection mode. Again, press the  for different color selection. Press  or idle any button for 5 seconds to leave the setting mode.

• Warning Value Setting (When the value is exceeded, the warning will be functional)

1. Select Exhaust Temp. Gauge icon by press  on Remote Controller.
2. Press  or  for entering the warning setting mode. Press  or  to adjust the warning value. Press  or idle any button for 5 seconds to leave the setting mode.

• Peak Value Setting

1. Select Exhaust Temp. Gauge icon by press  on Remote Controller.
2. Press  to display peak value record, or, press  to clear peak value record. Press  or idle any button for 5 seconds to leave the setting mode.

• OLED Display Function

When the Gauge is Booting, the OLED will show the Peak Value and warning setting value.

• Sensor Failure warning Function

After Booting, the gauge buzzer will show the warning sound about 20 seconds if the sensor is failed.